


## Installation Drawing



NOTE: PROVIDE TENSION SPRING BETWEEN SNAP EYE PULLEY & BAR OR BETWEEN CABLE DEAD & EYE STRAP..